

Product specifications for model 1203

Product Specifications (gauge,switch,relay)

sensor type	piston
functions	gauge, gauge/switch, switch
min. range	0-5 psid
max. range	0-150 psid
max. line pressure	5000 psig
min. burst pressure	15000 psig
standard maximum temperature	gauge: 200°F standard, 150°F (plastic lens) gauge/switch: 176°F standard, 150°F (plastic lens) switch: 176°F standard, 140°F relay
high temp. construction	gauge: 450°F (SST only, not available in aluminum or brass) gauge/switch,switch: 300°F (SST only, not available in aluminum or brass)
minimum temperature*	<i>*Consult factory for low-temperature applications.</i>
calibration accuracy**	±2% of full scale ascending after rap at room temperature <i>**Calibration accuracy is affected by temperature, and also by liquid-filling and follower-pointer options.</i>
repeatability	±2% of full scale
switches/relay	1 or 2 hermetically sealed reed switches or 1 relay in weatherproof enclosure
switch adjustability	upper 80% of full scale ascending (70% for B & C form switches in SST)
switch dead band	5-20% full scale
certification	CSA Class I,DIV. 2,Groups A,B,C & D; Class II,DIV. 2,Groups F & G (File 152872) NEMA 4X,IP65 <i>*Consult factory for CE equivalent.</i>

Standard configuration options (gauge,switch,relay)

configuration	unless otherwise specified	standard options available
porting size	1/4" NPT	1/2" NPT, AND, MS
porting orientation	in-line	N/A
direction of pressure	left to right	right to left (reverse porting)
calibration medium	all units with EPDM seals: water all others: alum or SS: hydraulic oil brass or PVC: water	N/A
switches & relays	(must be specified)	-A SPST N/O (120VAC,0.7A,70VA;200VDC,1.0A,50W) -B SPST N/C (120VAC,0.25A,5VA;175VDC,0.25A,5W) -C SPDT (120VAC,0.25A,5VA;175VDC,0.25A,5W) -R2 DPDT relay (contacts:120VAC,28VDC,10A coil:120VAC or 24VDC)
switch/relay setting	set at top of range ascending	other set points within adjustability ascending or descending
primary wetted parts	(must be specified)	aluminum, 316SS, naval brass, PVC
secondary wetted parts	range spring: 302SS magnet: ceramic piston seal: Teflon	Teflon-coated spring and magnet
static seals	buna-N, except Viton for high temp.	Viton,Teflon,neoprene,EPDM,fluorosilicone
lens	glass	plastic
dial sizes	(must be specified)	2.5", 3.5", 4.5", 6"
dial case styles	(must be specified)	"B" Basic Case (C-clamp not available) "F" Flanged Case (w/holes for panel mounting)
starting mark on dial	approximately 10% of full scale	N/A

Product specifications for model 1203

Product Specifications (transmitter)

sensor type	piston
functions	gauge/transmitter, transmitter (Loop powered)
min. range	0-5 psid
max. range	0-150 psid
max. line pressure	5000 psig
min. burst pressure	15000 psig
standard maximum temperature	gauge/transmitter: 200°F (glass lens), 150°F (plastic lens) transmitter: 200°F
high temp. construction	N/A
minimum temperature*	*Consult factory for low-temperature applications.
calibration accuracy**	±2% of full scale ascending after rap at room temperature **Calibration accuracy is compensated for temperature effects between -20 °F - 200 °F
repeatability	±2% of full scale
transducer enclosure	weatherproof
certification	CSA Class I, DIV. 2, Groups A, B, C & D; Class II, DIV. 2, Groups F & G (File 152872) NEMA 4X, IP65 *Consult factory for CE equivalent.

Standard configuration options (transmitter)

configuration	unless otherwise specified	standard options available
porting size	1/4" NPT	1/2" NPT, AND, MS
porting orientation	in-line	N/A
direction of pressure	left to right	N/A
calibration medium	all units with EPDM seals: water all others: alum or SS: hydraulic oil brass : water	N/A
electronic outputs	analog outputs: 4-20 mA (2 wire) 0-5 VDC (3 or 4 wire)	
supply voltage	9-35 VDC (reverse polarity protected)	
loop resistance	1300 ohms max. $R = ((V_s - 9) * 1000) / 20$ (ohms at V_s)	
board connection	1: + (EXC) 2: - 3: 0-5 V 4: COM	20-26 AWG wire
conduit connection	1/2" trade size	
primary wetted parts	(must be specified)	aluminum, 316SS, naval brass
secondary wetted parts	range spring: 302SS magnet: ceramic piston seal: Teflon	Teflon-coated spring and magnet
static seals	buna-N	Viton, Teflon, neoprene, EPDM, fluorosilicone
lens	glass	plastic
dial sizes	(must be specified)	2.5", 3.5", 4.5", 6"
dial case styles	(must be specified)	"B" Basic Case (C-clamp not available) "F" Flanged Case (w/holes for panel mounting)
starting mark on dial	approximately 10% of full scale	N/A